



INSTALLATION

1. INSTALL PRESSURE SWITCH

- (a) Coat a new O-ring with compressor oil.
- (b) Install the pressure switch to the liquid tube.

Torque: 10.8 N·m (110 kgf·cm, 8 ft·lbf)

2. CHARGE REFRIGERANT TO REFRIGERANT SYSTEM

- (a) Evacuate air from refrigeration system.
- (b) Charge system with refrigerant and inspect for leakage of refrigerant.

Specified amount: 500 ± 30 g (17.64 ± 1.06 oz.)

3. INSTALL LUGGAGE COMPARTMENT TRIM BOX COVER

4. INSTALL TOOL BOX ASSEMBLY