

<b>DTC</b>	<b>Normal</b>	<b>Source Voltage Drop</b>
------------	---------------	----------------------------

## CIRCUIT DESCRIPTION

The SRS is equipped with a voltage-increase circuit (DC-DC converter) in the airbag sensor assembly in case the source voltage drops.


When the battery voltage drops, the voltage-increase circuit (DC-DC converter) functions to increase the voltage of the SRS to normal voltage.

The diagnosis system malfunction display for this circuit is different from other circuits that is when the SRS warning light remains lit up and the DTC is a normal code, source voltage drop is indicated.

Malfunction in this circuit is not recorded in the airbag sensor assembly, and the source voltage returns to normal, the SRS warning light automatically goes off.

DTC No.	Diagnosis
(Normal)	Source voltage drop


## WIRING DIAGRAM



H14371

## INSPECTION PROCEDURE

### 1 Prepare for inspection.




#### PREPARATION:

- Disconnect the negative (–) terminal cable from the battery, and wait at least for 90 seconds.
- Remove the steering wheel pad (See page [SR-10](#)).
- Disconnect the connector of the front passenger airbag assembly (See page [RS-26](#)).
- Disconnect the connector of the airbag sensor assembly (See page [RS-41](#)).
- Disconnect the connector of the seat belt pretensioner RH and LH (See page [BO-59](#)).
- Disconnect the connector of the front airbag sensor RH and LH (See page [RS-46](#)).

#### CAUTION:

Store the steering wheel pad with the front surface facing upward.

### 2 Check source voltage.



#### PREPARATION:

- Connect the negative (–) terminal cable to the battery.
- Turn the ignition switch ON.

#### CHECK:

While operating the electric system (defogger, wiper, headlight, heater, blower, etc.), measure the voltage between each of terminals IG1 and IG2 of the airbag sensor assembly connector and body ground.

#### OK:


Voltage: 10 – 14 V

NG

Check harness between battery and airbag sensor assembly, and check battery and charging system.

OK

### 3 Does SRS warning light turn OFF?



#### **PREPARATION:**

- (a) Turn the ignition switch to LOCK.
- (b) Connect the steering wheel pad connector.
- (c) Connect the front passenger airbag assembly connector.
- (d) Connect the airbag sensor assembly connector.
- (e) Connect the seat belt pretensioner connector.
- (f) Connect the front airbag sensor connector.
- (g) Turn the ignition switch ON.

#### **CHECK:**

Operate electric system (defogger, wiper, headlight, heater blower, etc.) and check that SRS warning light goes off.

NO

**Check for DTCs. If a DTC is output, perform troubleshooting for DTC. If a normal code is output, replace airbag sensor assembly.**

YES

**From results of above inspection, suspected part can now be considered normal. To make sure of this, use simulation method to check.**