

PROBLEM SYMPTOMS TABLE

IGNITION SWITCH AND KEY UNLOCK WARNING SWITCH:

Symptom	Suspected Area	See page
Ignition switch is not set to each position	1. Ignition switch	BE-16
"Key unlock warning system" does not operate	1. GAUGE fuse 2. Key unlock warning switch circuit 3. Door courtesy switch circuit 4. Body control system 5. Combinationmeter 6. Wire harness	DI-364 DI-367 DI-377 DI-354 – IN-28

Warning Lights:

COMBINATION METER

Symptom	Suspected Area	See page
Door open warning light does not light up	1. LED 2. DOME fuse 3. Door courtesy switch circuit 4. Body control system 5. Meter circuit 6. Wire harness	– BE-9 DI-377 DI-354 BE-38 IN-28

POWER WINDOW CONTROL SYSTEM

Symptom	Suspected Area	See page
Power window does not operate	1. POWER fuse 2. GAUGE fuse 3. Body control system 4. Ignition switch 5. Power window control switch circuit 6. Wire harness	BE-9 DI-364 DI-354 BE-16 DI-368 IN-28
"One touch power window system" does not operate	1. Power window control switch circuit	DI-368
Only one window glass does not move	1. Power window control switch circuit 2. Power window motor circuit 3. Wire harness	DI-368 BE-52 IN-28
"Window lock system" does not operate	1. Power window control switch circuit	DI-368
Illumination does not light up	1. Power window control switch circuit	DI-368

POWER DOOR LOCK CONTROL SYSTEM

Symptom	Suspected Area	See page
"Door lock control system" does not operate (ALL)	1. Body control system 2. DOOR fuse 3. GAUGE fuse 4. Wire harness 5. Other parts	DI-354 DI-361 DI-364 IN-28 –
Malfunction in door lock/unlock (Using door manual switch)	1. Door lock control switch circuit 2. Body control system 3. Wire harness 4. Other parts	DI-376 DI-354 IN-28 –
Malfunction in door lock/unlock (Using door manual switch and key)	1. Wire harness 2. Other parts	IN-28 –
Malfunction in door lock/unlock (Using key)	1. Door unlock detection switch circuit 2. Body control system 3. Wire harness 4. Other parts	DI-372 DI-354 IN-28 –

Fault in 2-operation unlock function of driver's side door key lock and unlock switch	1. Door unlock detection switch circuit 2. Body control system 3. Wire harness 4. Other parts	DI-372 DI-354 IN-28 –
Fault in key confinement prevention operation	1. Door unlock detection switch circuit 2. Door courtesy switch circuit 3. Door lock control switch circuit 4. Body control system 5. Wire harness 6. Other parts	DI-372 DI-377 DI-376 DI-354 IN-28 –
Only one door lock does not operate	1. Door lock motor circuit 2. Wire harness	BE-56 IN-28

OTHERS

Symptom	Suspected Area	See page
Body ECU does not operate	1. Power source circuit 2. Body control system	DI-361 IN-28