

# REPLACEMENT

## REPLACEMENT REQUIREMENTS

In the following cases, replace the airbag sensor assembly.

- If the SRS has been deployed in a collision.
- If the airbag sensor assembly has been found to be faulty in troubleshooting.
- If the airbag sensor assembly has been dropped.

### CAUTION:

For removal and installation of the airbag sensor assembly, see pages [RS-41](#) and [RS-44](#). Be sure to follow the correct procedure.