


REASSEMBLY

1. INSTALL HEATER COVER

Install the heater cover with the screw.

2. INSTALL DEFROSTER NOZZLE

Install the defroster nozzle with the screw.



3. INSTALL HEATER RADIATOR

(a) Install the heater radiator.

(b) Install the clamp with the screw.