



INSTALLATION

1. INSTALL BLOWER UNIT

- (a) Install the blower unit with the 2 nuts and a bolt.
- (b) Install the ABS ECU with the bolt to the reinforcement.
- (c) Connect the blower motor connector.

2. INSTALL COOLING UNIT (See page [AC-31](#))

3. INSTALL INSTRUMENT PANEL (See page [BO-47](#))