







CLIP REPLACEMENT

BO020-06







The removal and installation methods of typical clips used in body parts are shown in the table below.

HINT:

If the clip is damaged during the operation, always replace it with a new clip.

Shape (Example)	Removal/Installation
	 <p>Clip Remover</p> <p>Pliers</p>
	 <p>Screwdriver</p>
	 <p>Scraper</p>

V00005

Shape (Example)	Removal/Installation	
	<p>Removal</p> 	<p>Installation</p> 
	<p>Removal</p> 	<p>Installation</p> 

V00012