



INSPECTION

INSPECT WASHER NOZZLE

While operating the washer, check that points where the washer fluid from the nozzles hits the windshield and applies great amount on certain area is within the range indicated by the hatched line, the washer nozzle is operating normally.

A: 263.2 mm (10.362 in.)

B: 256.7 mm (10.106 in.)

C: 379.2 mm (14.929 in.)

D: 150.4 mm (5.921 in.)

E: 405.2 mm (15.952 in.)

F: 201.6 mm (7.937 in.)

G: 182.2 mm (7.173 in.)

H: 406.5 mm (16.003 in.)

I: 150.0 mm (5.905 in.)

J: 50 mm (1.968 in.)