

























# ENGINE MECHANICAL

## SST (Special Service Tools)

PP2NG-01

	09032-00100	Oil Pan Seal Cutter	
	09201-01055	Valve Guide Bushing Remover & Replacer 5.5	
	09201-41020	Valve Stem Oil Seal Replacer	
	09202-70020	Valve Spring Compressor	
	(09202-00010)	Attachment	
	09213-70011	Crankshaft Pulley Holding Tool	
	09222-30010	Connecting Rod Bushing Remover & Replacer	
	09223-15030	Oil Seal & Bearing Replacer	Rear crankshaft seal
	09223-22010	Crankshaft Front Oil Seal Replacer	Crankshaft timing sprocket
	09308-10010	Oil Seal Puller	Front crankshaft seal
	09309-37010	Transmission Bearing Replacer	Front crankshaft seal
	09330-00021	Companion Flange Holding Tool	Crankshaft pulley

PREPARATION - ENGINE MECHANICAL

	09816-30010 Oil Pressure Switch Socket	
	09843-18040 Diagnosis Check Wire No.2	
	09950-50012 Puller C Set	
	(09951-05010) Hanger 150	Crankshaft pulley
	(09952-05010) Slide Arm	Crankshaft pulley
	(09953-05020) Center Bolt 150	Crankshaft pulley
	(09954-05020) Claw No.2	Crankshaft pulley
	09950-60010 Handle Set	
	(09951-00240) Handle Set	Drive belt idler pulley bearing
	(09951-00390) Handle Set	Drive belt idler pulley bearing
	09950-70010 Handle Set	
	(09951-07100) Handle 100	Drive belt idler pulley bearing Rear crankshaft oil seal