


























SUSPENSION AND AXLE













SST (Special Service Tools)

PP2DZ-02

| | | | |
|---|---------------|---|-------------------------|
|  | 09240-00020 | Wire Gauge Set | Rear drive shaft |
|  | 09310-35010 | Countershaft Bearing Replacer | Rear axle |
|  | 09506-35010 | Differential Drive Pinion Rear Bearing Replacer | Rear drive shaft |
|  | 09520-00031 | Rear Axle Shaft Puller | |
|  | (09520-00040) | Shocker | Front axle Rear axle |
|  | (09521-00010) | Attachment | Rear axle |
|  | (09521-00020) | Rod with Grip | Front axle Rear axle |
|  | 09521-24010 | Drive Shaft Boot Clamping Tool | |
|  | 09527-10011 | Rear Axle Shaft Bearing Remover | Front axle Rear axle |
|  | 09527-17011 | Rear Axle Shaft Bearing Remover | Rear axle |
|  | 09608-16042 | Front Hub Bearing Adjusting Tool | Rear drive shaft |
|  | (09608-02021) | Bolt & Nut | |

PREPARATION – SUSPENSION AND AXLE

| | | |
|---|--|--|
|  | (09608-02041) Retainer | |
|  | 09608-32010 Steering Knuckle Oil Seal Replacer | Rear axle |
|  | 09610-20012 Pitman Arm Puller | Front axle Rear axle Rear drive shaft Rear suspension |
|  | 09628-10011 Ball Joint Puller | Hub bolt |
|  | 09628-62011 Ball Joint Puller | Front axle Front suspension |
|  | 09710-04101 Base | Front axle |
|  | 09710-26011 Front Suspension Bushing Tool Set | Front lower suspension arm |
|  | (09710-05061) Replacer | |
|  | 09710-30021 Suspension Bushing Tool Set | Rear drive shaft |
|  | (09710-03141) Bushing Remover Base | |
|  | 09727-30021 Coil Spring Compressor | Front suspension Rear suspension |
|  | (09727-00010) Bolt Set | |
|  | (09727-00021) Arm Set | |

| | | |
|---|------------------------------------|---|
|  | (09727-00031) Compressor | |
|  | 09930-00010 Drive Shaft Nut Chisel | Rear axle Rear drive shaft |
|  | 09950-00020 Bearing Remover | Front axle Rear axle Rear drive shaft |
|  | 09950-60010 Replacer Set | |
|  | (09951-00380) Replacer 38 | Rear axle |
|  | (09951-00550) Replacer 55 | Rear axle |
|  | (09951-00650) Replacer 65 | Rear drive shaft |
|  | 09950-60020 Replacer Set No.2 | |
|  | (09951-00680) Replacer 68 | Front axle |
|  | (09951-00730) Replacer 73 | Rear axle |
|  | 09950-70010 Handle Set | Rear axle Rear drive shaft |
|  | (09951-07150) Handle 150 | |