

INSPECTION

1. VEHICLE NOT INVOLVED IN COLLISION

Check a diagnostic system (See page [DI-237](#)).

2. VEHICLE INVOLVED IN COLLISION WITH AIRBAG NOT DEPLOYED

Check a diagnostic system (See page [DI-237](#)).

3. VEHICLE INVOLVED IN COLLISION WITH AIRBAG DEPLOYED

Replace the airbag sensor assembly (See page [DI-237](#)).