

ENGINE IMMOBILISER SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

DI1KE-06

Troubleshooting in accordance with the procedure on the following pages.

